

Easy Start Instructions

1. Obtain an operational Mobile Phone SIM card.
2. Insert SIM Card into a mobile phone & turn off SIM PIN request.
3. Test SIM card by placing a call & an SMS, ensure that caller I.D is visible.
4. Remove SIM card from phone when completed.
5. Place the tested SIM card into the Live Track GPS Tracker as seen below:



6. Insert Live Track GPS Battery (It can only fit in one way)
7. You will notice that the green LED light will flash once or twice, don't do anything else at this stage
8. The Live Track GPS Tracker will run through a short self-test and then you will see the green LED light flash rapidly.
9. Take the Live Track GPS tracker into an outdoor space with a clear view of the sky.
10. The Green LED light should then flash once every 5 seconds, this is an indication that the Live Track GPS unit has acquired a GPS signal.
11. Send the Live Track GPS Tracker an SMS from the mobile phone you intend to use as the monitor phone, the SMS text should contain **begin123456** (123456 is the default password). This will initialise the Live Track GPS unit and prepare it for operation.
12. If you did everything correctly, you should receive an SMS from the Live Track GPS Tracker with the text as **BEGIN O.K!**
13. To set the monitor phone number, just place a call the Live Track GPS Units 10 times, the Live Track GPS tracker will then send you an SMS with the GPS information when the monitor number has been set.
14. You are now ready to start tracking, place the Live Track GPS Tracker on your target object, then just place a normal phone call to the Live Track GPS tracker from the monitor phone when you want it to report a location.
Please see Full instructions for all other features.

F.A.Q (Trouble Shooting)

Q: Green LED Light continuously flashing

A: This is usually caused by either a GPS signal cannot be acquired or SIM card not inserted

Q: Can't receive SMS from Live Track GPS

A: Check that you have sufficient credit on the SIM card inside the Live Tracker GPS Unit & make sure that you calling with your caller I.D visible

Q: Receiving the incorrect GPS coordinates

A: The Live Track GPS Tracker is usually accurate within 50M max, but if you experiencing this then you can reset the Live Track by sending an SMS to the device containing the text **begin123456**, this will reset the device. Be sure to set your monitor number again by call the device 10 times.

Please see FULL instruction manual for All other troubleshooting